


1. REMOVE RING AS SHOWN.



2. PRESS GUARD DOWN OVER OPERATOR, TIGHTEN SCREWS IN GUARD.